

JohnDeere170_MowerOperation

Check the Oil level (under the hood) and Fuel level (under the seat) - add if needed.

Sit in the mower seat.

Place the Movement Control (A) in the "N" (neutral)



Move the throttle lever (E) all the way up (Choke position)



With your feet, hold both the Brake Pedal (B) and Clutch Pedal (D) down.

Turn the Key (C) to the start position until the motor starts, then move the throttle lever (E) to the mid range position.

Move the Movement Control lever (A) to the "R" (reverse) position, release the Brake and Clutch Pedals and back out of the hanger.

Push in the Clutch Pedal, shift the Movement Control lever (A) to a forward speed and drive to the area you want to start mowing.

Push in the Clutch Pedal (D), shift the Movement Control Lever (A) to the forward speed you want to mow at.

Turn on the Mower Blades Switch (G) and lower the Deck Lift Lever (F).

Release the Clutch Pedal (D) and MOW!

